


## Use & Fitting of hose to V-TUF automatic retractable reels.



### Fitting of hose:

1. Insert the hose end that is being connected to the hose through the roller bracket (number 1).
2. Feed the same end through the connection hole in the drum (number 2) and connect the hose to the connection in the hub of the reel. Please note: Do **not** wind on more than the maximum length of hose stated for the reel.
3. Wind on the hose by turning the reel drum in the direction of arrow (number 3).
4. Once the hose is on the reel, fit the hose stopper (number 6) to the hose.
5. Feed the supply hose from the water source/pump to connection (number 4)
6. Before using, please ensure the hose reel is properly secured to a stable surface through all four mounting holes (number 5)

### Use of reel:

When you pull the hose from the reel, you will notice that there will be an alternation between 'clicks' and 'quiet'.

1. When you hear the 'clicks' and you stop pulling the hose, the reel will lock (not retract at that point)
2. In the 'quiet' points the reel will retract when released.
3. Do not let the hose go when retracting, feed hold the hose and feed it back on the reel and the reel will retract automatically.
4. It is best practise to release the pressure in the system when retracting or protracting the hose from the reel.